



How to Access a Uniview Device's Web Interface through EZCloud Account?

Title	How to Access a Uniview Device's Web Interface through EZCloud Account?	Version:	V1.2
Product	SMB	Date	4/25/2025

How to Access a Uniview Device's Web Interface through EZCloud Account?

Description

Note: This method is applicable to most of the scenarios. If the method still cannot solve your problem, it is recommended to consult our Tech Support Team.

https://global.uniview.com/Support/Service_Hotline/


Operating Steps

You can access the web interface from EZCloud website or EZStation.


From EZCloud Website:

Step 1 Please visit the EZCloud website and log in your EZCloud/EZView account.


<https://global.ezcloud.uniview.com/login>




Step 2 Download the P2P plugin and install it.




Title	How to Access a Uniview Device's Web Interface through EZCloud Account?	Version:	V1.2
Product	SMB	Date	4/25/2025

Step 3 Find the device you wish to access from **My Cloud Devices** or **Devices Shared to Me** under **Device Management**. Click  under the **Operation** column to access the web interface of this device.




From EZStation:


Step 1 Log in your EZStation and the cloud account under **Device Management>Cloud Device**.



Step 2 Go to **Device Details** to add the devices to manage if it has not been added before.

Title	How to Access a Uniview Device's Web Interface through EZCloud Account?	Version:	V1.2
Product	SMB	Date	4/25/2025



Step 3 Go back to **Cloud Device** and find the device you wish to access the web interface of. Click  under the Operation column.

